

Need some maintenance tips for your Quick-Step Laminate floor?

Then look no further:

Your Quick-Step Laminate floor has a sealed surface, which prevents any build-up of bacteria and makes it both easy to clean and hygienic.

To wet clean your floor, you'll need a small amount of Quick-Step cleaning product, that's 2 capfuls in a typical 10 litre bucket.

It's best to vacuum your floor at least once a week to remove dust and dirt and wet clean the floor at least every other week.

Only use a vacuum cleaner with soft wheels and a special soft brush to avoid scratches.

Mop your planks lengthways in small sections to avoid drying streaks.

Before wet cleaning always make sure you thoroughly vacuum the floor to remove surface dust and debris.

You'll need two buckets and a mop, fill one bucket with water and a small amount of cleaning solution, the other with clean water to rise your mop.

Moisten the mop in the bucket containing the cleaning solution, mop the floor, rinse the mop in clean water, wring it out well and wipe your floor until it's entirely dry.

Always lift furniture rather than dragging it and use felt pads under the feet where possible.

Never use abrasive cleaning products as these can damage your floor.

Where possible use mats and chairs with soft wheels and feet to minimise the possibility of scratching the floor.

Always use the manufacturers cleaning products to ensure compatibility, follow the instructions on the bottles.

Never attempt to steam clean a laminate floor, this will invalidate any warranty.

That's it, enjoy your floor.

